Cetis | APPLIANCES
Teledex • TeleMatrix • Scitec

User Guide
Hand-Held Garment Steamer (I-900)

IMPORTANT SAFETY INSTRUCTIONS

IMPORTANT SAFEGUARDS

1. Before using this product for the first time, please check whether the pressure stated on the product nameplate is consistent with the one you are using.

2. Do not use products if they are damaged in any way.

3. Use pure water as much as possible, and no liquid other than clean water is allowed in the water tank.

4. Before filling and cleaning, unplug from outlet and fill the tank with water according to instructions.

5. When using, do not touch the bottom plate, hot water, or steam as to prevent scalding.

6. Pay attention, do not let steamer run in one direction/on surface area for too long, do not face others during.

7. Be careful not to touch the hot bottom plate.

8. Do not immerse appliance in any liquid to clean.

9. Please practice supervision after plugging in appliance. The immediate heating system when turned on may cause shortage in the circuit breaker.

10. This machine must only be used for ironing, do not use for other purposes.

11. Do not use if appliance has been dropped, has visible signs of damage, or leakage.

12. Be sure unit is unplugged and completely cool before attaching accessories.

13. Before storage, make sure that the steamer is completely cooled and drain the water from the machine.

14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

15. WARNING If packaging is damaged, it must be replaced by the manufacturer, its maintenance department, or a similar tester in order to avoid a dangerous inspection.

SAVE THESE INSTRUCTIONS.
HOUSEHOLD USE ONLY.

Dear customers, thank you for purchasing Cetis garment stea. For your proper use and maintenance of the electric kettle, please read this user manual carefully before use, which will help you use the product. If you have any doubt about the product or warranty, please contact us, and thank you again for your purchase!

Thank you for purchasing the Cetis garment steamer. Please read this user guide before use. If you have any questions, please contact us at www.cetisappliances.com

PACKING LIST

The packaging box includes the following items:
- Garment Steamer
- Rubberized cord and plug
- Water Reservoir

Part Names:

Pilot lamp

Steam outlets

Water reservoir

Bottom panel iron

Steam switch

Handle

Hanging hooks

PRODUCT FEATURES

- Small size, easy to lift, unlimited use
- Three-state automatic shut off for safety
- Wear-resistant and non-sticking base plate
- Quick preheating in 30 seconds, enjoy wrinkle-free clothes at any time
- Easily operated, one-button steam system
- Efficient, high-temperature secondary vaporization for automatic steam
- Adjustable components and convenient outlet cord for easy storage
- Comes in colors: Space Gray and Black

OPERATING INSTRUCTIONS

Water placement:

1. Turn the water tank on the back counterclockwise until it is loosened; pull out the water tank.

2. Open water port (rubber tab), add pure water until full, and reassemble components (plug rubber tab back over port).

3. Reinstall the tank. According to the position on the reservoir, turn the water tank in the correct direction until it clicks fully in, installing it back into place.

Ironing:

1. Insert the plug into a fixed socket, at this time the "working" indicator at the top of the appliance will light up and the machine should be charging.

2. After the machine is plugged in, fully preheat it for about 30 seconds. After the preheating indicator is off, press the steam switch to start exhausting steam from steam outlets.

3. Continually hold the switch to release steam, use a firm grip on handle to hold appliance, and release switch to pause steam release.

Note: The garment steamer heats up immediately after being plugged in.

1. When finished, unplug and let the garment steamer cool down sufficiently before storing it.
2. Empty the water tank and let out excess steam.

Precautions

Automatic Shut Off function:

- After the garment steamer is left in a static state for at least 20 minutes, the machine will automatically turn off.

- If you want to continue use it after shut off, simply unplug then plug the garment steamer back into the outlet, where it will restart as normal.

Safety and cleaning:

1. Before cleaning the appliance, unplug the power plug first, and make sure the machine is completely cooled.
2. Scale and dust the surface, use a soft cloth dipped in a neutral detergent to wipe it.
3. Mix 10% white vinegar with 90% water, pore into steam port, wait for 30 minutes, and drain the tank. Repeat several times to remove scaling.
4. After cleaning, empty the water tank, drain excess water, and put in a cool and dry place that's out of reach of children.
5. Do not immerse in water or other solutions.
6. Do not add vinegar, dish soap, perfume, etc. to the water tank. In order to extend use, please only use distilled water.

COMMON FAILURES AND SOLUTIONS

Fault	Reason
No Steam	- Check whether it is open, if the steam button is pressed, and how much water is in the reservoir. Notify maintenance for any missing parts.
Water Spray on Ironing Plate	- Wait until the steamer is fully heated before using it, if it is not resolved, clear notice for maintenance.

TECHNICAL PARAMETERS

- Product Name : Garment Hanging Iron
- Household type : 1-900
- Rated source : 220V~50Hz/ 120v~60HZ
- Rated Power : 1000W
- Water tank capacity : 100ml/ 3.38 fl oz
- Size : 170 x 89 x 240mm/ 6.69 x 3.50 x 9.45in (including water tank)
- Weight : 638g/1.40lbs

www.cetisappliances.com

4975 N. 30th Street
Colorado Springs, CO 80919

info_USCA@cetis.com
Telephone +1 719 638 8821
Fax +1 719 638 8757

CTS-APP-UG-GSTM-122024