

The background of the entire page is composed of intricate, flowing, and overlapping blue lines that resemble smoke or liquid in motion. These lines vary in opacity, creating a sense of depth and movement. They are primarily concentrated on the left side and top, with some lines extending towards the right.

Cetis  | APPLIANCES  
Teledex • TeleMatrix • Scitec

# **User Guide**

## **Flashlight (FL-102)**





**Black FL-102**  
**Part Number: FL1021 (12 per case)**

## **PACKING LIST**

Included in the box:

- Flashlight
- Flashlight base
- User guide



## PRODUCT FEATURES

- Patented series design
- Aesthetic, non-slip, threaded handle
- Has luminescent light ring so the flashlight can be found in low- or no-light conditions
- Uses high-efficiency, energy-saving, long-life LED lamp beads
- Use two LR6 AA 1.5V AA batteries
- Available in Black or Grey



## OPERATING INSTRUCTIONS

1. Install the base in place.
2. When in use, just remove the flashlight from the base, and the light will automatically turn on.
3. After use, put the flashlight into the base, the light will turn off automatically.

### Replacing Batteries

1. Rotate the bottom cover of the flashlight counterclockwise and remove the bottom cover.
2. Insert two LR6 AA 1.5V batteries into the flashlight in the direction shown in the diagram.
3. Rotate the bottom cover of the flashlight clockwise and screw the bottom cover tightly.







**COMMON FAILURES AND SOLUTIONS**

Failure	Solution
The flashlight does not work.	<ul style="list-style-type: none"><li>• If the white LED fails or internal parts fail, the unit will need to be returned for repair.</li><li>• Please insert or replace the LR6 AA 1.5V battery before use</li></ul>

**TECHNICAL PARAMETERS**

**Product name:** Flashlight

**Product model:** FL-102

**Battery capacity:** LR6 AA 1.5V batteries \* 2

**Dimensions:** 1.85 x 1.85 x 7.20 in (47 x 47 x 183 mm)

**Weight:** 0.26lbs (119 g)







**White FL-102**  
**Part Number: FL1026 (12 per case)**



The background of the entire page is an abstract, flowing pattern of light blue and white, resembling smoke or liquid waves. The pattern is composed of many thin, overlapping lines that create a sense of movement and depth.

**[www.cetisappliances.com](http://www.cetisappliances.com)**

**4975 N. 30th Street  
Colorado Springs, CO 80919**

**info\_USCA@cetis.com  
Telephone +1 719 638 8821  
Fax +1 719 638 8757**

© 2022 Cetus, Inc. Cetus, Inc. is a U.S. corporation, incorporated in the State of Delaware and headquartered in Colorado. Product specifications and descriptions in this document subject to change without notice. Cetus®, Teledex®, TeleMatrix®, and Scitec® are trademarks or registered trademarks of Cetus, Inc.

**CTS-APP-UGFL-112022**